MixTrack Edge Update Instructions

1. Connect MixTrack Edge to the computer via USB.

2. Follow the in-app instructions carefully, making sure the MixTrack Edge stays connected during the update process. The firmware update is located in the "Firmware" folder in the zip file.

3. Once the LEDs on the MixTrack Edge have stopped blinking and the Updater has confirmed the successful update, the Updater software can be closed and the MixTrack Edge is ready to use.