

Numark DJ2GO Traktor TSI Release Notes

This setup file will work with Traktor 1 and 2, this is not compatible with Traktor LE software.

Installation Instructions:

1. Connect the Numark DJ2GO to your computer and open Traktor 1 or 2
2. In Traktor go to **File**→**Preferences**. Click the Import button at the bottom of the window.
3. Select **DJ2GOTraktor.tsi**
4. Your controller is now ready to work with Traktor.

Controls:

All keys and knobs on the DJ 2 GO function as they are labeled with TRAKTOR 1&2, with the exception of the “BACK” button.

The “BACK” button acts as a “SHIFT” function inside TRAKTOR.

COMMAND	FUNCTION
BACK + BROWSE	Ranges between folders in the FOLDER TREE
BACK + PLATTER A/B	Seeks across track at higher rate
BACK + CUE MONITOR A/B	Engages FILTER ON/OFF for the desired deck
BACK + CHANNEL VOLUME A/B	Controls FILTER for desired deck