

PITCH SLIDER AND WHEEL RECALIBRATION PROCEEDURE

Following any program updates you should recalibrate your CD player. This will recenter the pitch slider and align the jog wheel for optimal performance. You should do this on your AXIS CD player and both sides of your CDN90 CD unit.

