

NDX800 – Controller Setup in CUE 6

1. Download the latest version of CUE from webpage below. You will be asked to enter your Authorization Code. Once downloaded, install the software.
 - www.numark.com/cueupdate
2. Download the [NDX800 – CUE Controller Mapping File](#) from the CUE product page on numark.com:
 - www.numark.com/cue
3. Once downloaded to your computer, uncompress the file titled **NDX800 - CUE Controller Mapping File.zip**. The file you'll download is a .zip file that needs to be **uncompressed**, or **un-zipped**. Many computers come with a utility pre-installed to un-zip .zip files. Simply double-clicking on the .zip file will often open the utility and allow you to uncompress the file.

Windows Users:

If double-clicking the file does not automatically uncompress it, try right-clicking the file, and selecting **Explore**, or **Extract**. These options should allow you to access the contents of the file.

If needed, you can download a free un-zipping utility for the PC called **WinRar** at download.com

Macintosh Users:

Macintosh users of OS 10.3 or later can simply double-click the file to un-zip it.

Macintosh users of earlier operating systems can download a free unzipping utility called **Stuffit Expander** at <http://www.stuffit.com/mac/expander/trial.html>

Once un-zipped, you'll have an folder called **NDX800 - CUE Controller Mapping File**.

4. Inside this folder you'll find a file called **Numark NDX800 mapping.xml**. Copy this file to the following location on your computer:

Windows:

C:\Documents and Settings\[YourUserNameHere]\My Documents\Numark Cue\Mappers

Macintosh:

Macintosh HD > Users > [YourUserNameHere] > Documents > Numark Cue > Mappers

5. On each NDX800 unit, press the **SOURCE** button, then use the **PARAMETER** knob to set the source to **USB-MIDI**. Press the **PARAMETER** knob (like a button) to confirm your selection.
6. Next, launch CUE. Once opened, click the **Config** button in the upper-right of the screen to open the Settings window



7. At top of the window that opens, select **Mappers** tab.
8. Click the **Mappers Options** button.



9. In the pop-up menu that opens, un-check any items that are checked.



10. Next, to the left of the **Mappers Options** button, select **Numark NDX-800**



11. Then, click the **Mappers Options** button again, and check **Use MIDI devices**.



12. Lastly, click the **Mappers Options** button again, and select **Rescan for new devices**.